



НАСТРОЙКА РОУТЕРА D-LINK (Вариант 1)

1. Подключите кабель от компьютера в один из LAN-портов роутера (обозначены цифрами), а затем подключите кабель, идущий из подъезда, в WAN-порт (либо Ethernet) роутера.
2. Зайдите на роутер через любой браузер на вашем ПК, указав необходимый адрес в адресной строке браузера (его адрес по умолчанию — <http://192.168.0.1/>).
3. В открывшемся окне введите логин от роутера (по умолчанию **admin**). Поле пароль по умолчанию должно оставаться пустым. Для начала настройки выберите в меню посередине вкладку **SETUP**, затем в меню слева выберете **Internet Setup** и в открывшемся окне нажмите кнопку ниже **Manual Internet Connection Setup**.



4. В открывшемся окне выбираем и вводим следующие параметры:
 - My internet connection is – **PPPoE (Username/password)**;
 - **Dynamic PPPoE**;
 - User Name – указываете логин из памятки абонента;
 - Password - указываете пароль из памятки абонента;
 - Retype Password – повторно указываете пароль из памятки абонента;
 - Сохраните настройки кнопкой «**Save Settings**»

Product Page : DIR-320



DIR-320 // SETUP ADVANCED MAINTENANCE STATUS

Internet Setup
Wireless Setup
LAN Setup
Printer Setup
Time and Date
Parental Control
Logout

Internet Online
Reboot

INTERNET CONNECTION

Use this section to configure your Internet Connection type. There are several connection types to choose from: Static IP, DHCP, PPPoE, PPTP, L2TP, Russia PPTP(Dual Access) and Russia PPPoE(Dual Access). If you are unsure of your connection method, please contact your Internet Service Provider.

Note: If using the PPPoE option, you will need to remove or disable any PPPoE client software on your computers.

Save Settings Don't Save Settings

ACCESS POINT MODE

Use this to disable NAT on the router and turn it into an Access Point.

Enable Access Point Mode **X**

INTERNET CONNECTION TYPE

Choose the mode to be used by the router to connect to the Internet.

My Internet Connection is : PPPoE (Username / Password) ✓

PPPOE

Enter the information provided by your Internet Service Provider (ISP).

Dynamic PPPoE Static PPPoE

User Name : Сюда логин ✓
 Password : Сюда пароль ✓
 Retype Password : Сюда пароль ✓
 Service Name : fregat (optional) ✓
 IP Address : - - - (optional)
 MAC Address : - - - (optional)

Receive DNS from ISP Enter DNS Manually

Primary DNS Address :
 Secondary DNS Address : (optional)
 Maximum Idle Time : Minutes
 MTU : 1492
 Connect mode select : Always Manual Connect-on demand

Save Settings Don't Save Settings

5. Настраиваем Wi-Fi соединение. Для этого выберите в меню посередине вкладку **SETUP**, затем в меню слева выберите **Wireless Setup** и в открывшемся окне нажмите кнопку ниже **Manual Wireless Connection Setup**:

Product Page : DIR-320



DIR-320 // SETUP ADVANCED MAINTENANCE STATUS

Internet Setup
Wireless Setup
LAN Setup
Printer Setup
Time and Date
Parental Control
Logout

Internet Online
Reboot

WIRELESS CONNECTION

There are 2 ways to setup your wireless connection. You can use the Wireless Connection Setup wizard or you can manually configure the connection.

Please note that changes made on this section will also need to be duplicated to your wireless clients and PC.

WIRELESS CONNECTION SETUP WIZARD

If you would like to utilize our easy to use Web-based Wizard to assist you in connecting your new D-Link Systems Wireless Router to the Internet, click on the button below.

Note: Before launching the wizard, please make sure you have followed all steps outlined in the Quick Installation Guide included in the package.

MANUAL WIRELESS CONNECTION OPTIONS

If you would like to configure the Internet settings of your new D-Link Router manually, then click on the button below.

6. В открывшемся окне выбираем и вводим следующие параметры:

- WiFi protected setup (WCN2.0) – отключить ;
- Enable Wireless – включить ;
- Wireless Network Name (SSID) – придумайте название для вашей сети под которым она будет видна в списке беспроводных сетей;
- Enable Auto Channel Selection – включить;
- WMM Enable – отключить;
- Enable Hidden Wireless – отключить;
- Security Mode – WPA/WPA2;
- Cipher type – TKIP;
- PSK/EAP – PSK;
- Network key – придумайте пароль для подключения к вашей домашней беспроводной сети (мин 8 символов, английские буквы и цифры);
- Нажмите «**Save Settings**» – настройки будут сохранены.

Product Page : DIR-320

D-Link

DIR-320 // SETUP ADVANCED MAINTENANCE STATUS

Internet Setup
Wireless Setup
LAN Setup
Printer Setup
Time and Date
Parental Control
Logout

Internet Online
Reboot


WIRELESS NETWORK

Use this section to configure the wireless settings for your D-Link router. Please note that changes made on this section may also need to be duplicated on your wireless client.

To protect your privacy you can configure wireless security features. This device supports three wireless security modes including: WEP, WPA and WPA2.

Save Settings Don't Save Settings

WI-FI PROTECTED SETUP (ALSO CALLED WCN 2.0 IN WINDOWS VISTA)

Enable : 


Current PIN : 30818064


Generate New PIN Reset PIN to Default

Wi-Fi Protected Status : Disabled / Configured

Reset to Unconfigured Add Wireless Device with WPS

WIRELESS NETWORK SETTINGS

Enable Wireless : 

Wireless Network Name : Сюда название сети  (Also called the SSID)

Enable Auto Channel Selection :


Wireless Channel : 6

Transmission Rate : Best (automatic) (Mbit/s)

WMM Enable : (Wireless QoS)


Enable Hidden Wireless : (Also called the SSID Broadcast)


WIRELESS SECURITY MODE


Security Mode : Enable WPA/WPA2 Wireless Security (enhanced) 


WPA/WPA2

WPA/WPA2 requires stations to use high grade encryption and authentication.

Cipher Type : TKIP 

PSK / EAP : PSK 

Network Key : Сюда - ключ сети 
(8~63 ASCII or 64 HEX)

Save Settings  Don't Save Settings

Базовая настройка роутера завершена!